# 1990-98 MAZDA 323/PROTEGE CHASIS SCHEMATICS

1995-98

1995-98

HOT AT ALL TIMES
IG
FUSE
50 A

B

IGNITION
SWITCH

START
ACCY
RUN
LOCK

B/BL

STARTER
INTERLOCK
SWITCH
(M/T)
TRANSAXLE
RANGE
SWITCH
(A/T)

BATTERY

B/R

R

B

STARTER

M

B

B

HOT AT ALL TIMES
MAIN
FUSE
LINK
80A
(95-96)

MAIN
FUSE
LINK
I00A
(97-98)

B/W

GENERATOR

VOLTAGE
REGULATOR

1995-96          1997

W/B          B/G          B

B

TO
INSTRUMENT
CLUSTER

TO
PCM

HOT AT ALL TIMES
INJ
FUSE
LINK
30 A

TO
PCM

W/G          R/G

1995-96          1997-98

W/G OR R/G

1995-96          1997-98

---

1995-96

HOT AT ALL TIMES
COOLING
FAN
20A

HOT IN START OR RUN
ENGINE
10A

B/R          B/W

COOLING
FAN
RELAY

Y          P/B

M          COOLING
FAN
MOTOR

B

TO
PCM

1990-94

HOT AT ALL TIMES
INJ
FUSE
LINK
30A

HOT IN START OR RUN
ENGINE
15A

W/G          B/W

TO
MAIN
RELAY

B

TO
ENGINE
CONTROL
UNIT

V          W/R

CIRCUT
OPENING
RELAY

4x4
CONTROL
UNIT

B          L/G          B/P

BL/R          LG/Y

M          FUEL
PUMP

M          TRANS-
FER
PUMP

B          B

TO
ENGINE
CONTROL
UNIT

1995-98

TO
MAIN
RELAY
(HOT IN START OR RUN)

W/R

W/R          W/R

FUEL
PUMP
RELAY

L/G          B/P

TO
PCM

M          FUEL
PUMP

B

DIAGRAM 27