## 1991-93 MAZDA NAVAJO CHASSIS SCHEMATIC HOT AT ALL TIMES HOT AT ALL TIMES W/O DRL HOT IN RUN OR START HOT AT ALL TIMES **P** CIRCUT FUSE FUSE FUSE BREAKER 15A 15A 20A 20A COMBINATION SWITCH W/ SPEED W/O SPEED CONTROL CONTROL OFF • • ON PARK BACK-UP SWITCH CLOCKSPRING HORN RELAY TO SPEED CONTROL FLASH HIGH TO BEAMS PASS W/ SPEED CONTROL W/O SPEED CONTROL R/B HORN HORN LEFT HEADLIGHT RIGHT HEADLIGHT LEFT BACK-UP LIGHT HIGH RIGHT BACK-UP LIGHT BEAM INDICATOR LIGHT HOT AT ALL TIMES FUSE 10 15A COMBINATION SWITCH OFF • ON PARK BR BR BR BR TO TURN/ TO TURN/ HAZARD SWITCH HAZARD SWITCH LEFT LICENSE PLATE LIGHT LEFT REAR STOP/ TURN/ PARK LIGHT LEFT FRONT PARK/ RIGHT LEFT RIGHT RIGHT RIGHT FRONT SIDE MARKER LICENSE PLATE LIGHT REAR STOP/ TURN/ FRONT FRONT PARK/ SIDE MARKER TURN LIGHT TURN PARK LIGHT LIGHT LIGHT LIGHT

DIAGRAM 18